

## Sensor Operation

### DIP Switch Setting

#### Detection Area

Dip switch	1	2
100%	ON	ON
75%	-	ON
50%	ON	-
25%	-	-

#### Hold time

Dip switch	3	4	5
5 sec	ON	ON	ON
30 sec	-	ON	ON
90 sec	ON	-	ON
5 min	-	-	ON
20 min	ON	ON	-
30 min	-	---	-

#### Daylight Threshold

Dip switch	6	7	8
2 lux	ON	ON	ON
10 lux	ON	ON	-
30 lux	-	ON	-
50 lux	ON	-	-
Off	-	-	-

Factory setting is 100% detection, 5 seconds hold time and daylight sensor disabled.

The sensor may be overridden by switching the luminaire on and off rapidly three times. To turn sensor operation on again, switch the luminaire on and off rapidly once.

#### Initialization

After power on, the sensor automatically turns on light at 100% brightness. After 10sec, it turns off the light. During the initialization, the sensor is not able to detect movement.

## Sensorinställning

### Känslighet

Dip switch	1	2
100%	ON	ON
75%	-	ON
50%	ON	-
25%	-	-

### Efterlystid

Dip switch	3	4	5
5 sek	ON	ON	ON
30 sek	-	ON	ON
90 sek	ON	-	ON
5 min	-	-	ON
20 min	ON	ON	-
30 min	-	---	-

### Ljusrelä

Dip switch	6	7	8
2 lux	ON	ON	ON
10 lux	ON	ON	-
30 lux	-	ON	-
50 lux	ON	-	-
Off	-	-	-

Fabriksinställning är 100% känslighet, 5 sekunder efterlystid och ljusreläet avslaget.

### Bortkoppling

Sensorn kan kopplas bort genom att snabbt slå av och på armaturen tre gånger. För att återställa sensorfunktionen, slå av och på armaturen snabbt en gång.

### Uppstart

När armaturen spänningssätts kommer sensorn tända upp armaturen 100%. Efter 10 sekunder släcks armaturen. Under uppstarten sker ej någon detektering.